



## WARNING

INCORRECT USE MAY RESULT IN INJURY OR DEATH! USE ONLY ON FLAT HARD LEVEL SURFACES.  
RAMPS TO BE USED IN PAIRS. CHOCK AT LEAST ONE WHEEL ON THE GROUND

## INSTRUCTIONS FOR USE

- A.** Use ramps on hard level surface, such as concrete.
- B.** Confirm that the load to be applied does not exceed the working load limit of the vehicle ramps.
- C.** Conduct a pre-operational check of the equipment.
- D.** Ramps should be used in pairs.
- E.** Check that no part of the underbody of the vehicle will foul as the ramps are positioned.
- F.** Turn the wheels to a straight ahead position and place the ramps against the tyres in such a way that each ramp is in line with the respective wheel.
- G.** Slowly drive the vehicle onto the ramp platform with guidance from a person outside the vehicle.
- H.** Apply the parking brake.
- I.** Place a chock under at least one of the wheels which is on the ground so that the vehicle cannot accidentally roll off the ramps.
- J.** Modifications must not be carried out or accessories added.

## **PART NO. CRC4WD** **1000kg Vehicle Car Ramps**

COMPLIES WITH PORTABLE RAMP  
SAFETY STANDARD AS 2640:2017

Working Load Limit 1000kg per ramp  
Maximum Tyre Diameter 780mm  
Maximum Tyre Width 250mm



MADE IN AUSTRALIA