



Incline Rung	Α	В	С	D	E	F	G	н
Measurement from top peak of angle iron rung on incline to ground	40mm	70mm	100mm	125mm	150mm	190mm	230mm	225mm



PART NO. CRTP1400 1400KG – Two piece low profile car ramp





WARNING

INCORRECT USE MAY RESULT IN INJURY OR DEATH! USE ONLY ON FLAT HARD LEVEL SURFACES.

RAMPS TO BE USED IN PAIRS. CHOCK AT LEAST ONE WHEEL ON THE GROUND

INSTRUCTIONS FOR USE

- A. Use ramps on hard level surface, such as concrete.
- **B.** Confirm that the load to be applied does not exceed the working load limit of the vehicle ramps.
- C. Conduct a pre-operational check of the equipment.
- **D.** Ramps should be used in pairs.
- E. Check that no part of the underbody of the vehicle will foul as the ramps are positioned.
- **F.** Turn the wheels to a straight ahead position and place the ramps against the tyres in such a way that each ramp is in line with the respective wheel.
- **G.** Slowly drive the vehicle onto the ramp platform with guidance from a person outside the vehicle.
- H. Apply the parking brake.
- I. Place a chock under at least one of the wheels which is on the ground so that the vehicle cannot accidently roll off the ramps.
- J. Modifications must not be carried out or accessories added.

INSTRUCTIONS FOR ASSEMBLY

- A Only use the ramps when fully assembled
- **B** On hard level surface place the hooks on the rear section into the loops on the front section, repeat for both ramps
- **C** Check the ramps are properly aligned
- D Confirm the hooks and looks are fully engaged
- E Ramps are ready for use

OPTIONAL – BOLT RAMP SECTIONS TOGETHER FOR EASE OF MOVEMENT

- 1 Locate the bolt and washer pack included with ramps
- 2 Ensure the ramps are assembled as per instructions A-D
- **3** Place washer on bolt insert bolt through rear hook and front section via pre-drilled hole
- 4 Place washer on inserted bolt and tighten with nut firmly
- 5 Repeat on other side and for second ramp



