



WARNING

INCORRECT USE MAY RESULT IN INJURY OR DEATH! USE ONLY ON FLAT HARD LEVEL SURFACES.
RAMPS TO BE USED IN PAIRS. CHOCK AT LEAST ONE WHEEL ON THE GROUND


INSTRUCTIONS FOR USE

- A.** Use ramps on hard level surface, such as concrete.
- B.** Confirm that the load to be applied does not exceed the working load limit of the vehicle ramps.
- C.** Conduct a pre-operational check of the equipment.
- D.** Ramps should be used in pairs.
- E.** Check that no part of the underbody of the vehicle will foul as the ramps are positioned.
- F.** Turn the wheels to a straight ahead position and place the ramps against the tyres in such a way that each ramp is in line with the respective wheel.
- G.** Slowly drive the vehicle onto the ramp platform with guidance from a person outside the vehicle.
- H.** Apply the parking brake.
- I.** Place a chock under at least one of the wheels which is on the ground so that the vehicle cannot accidentally roll off the ramps.
- J.** Modifications must not be carried out or accessories added.

PART NO. CRS850 **850kg Vehicle Car Ramps**

COMPLIES WITH SAFETY STANDARDS
AS/NZS 2640:1994
AS 2640:2016

Working Load Limit 850kg per ramp
Maximum Tyre Diameter 650mm
Maximum Tyre Width 200mm



MADE IN AUSTRALIA